



Groleau Flooring inc.
541, Dalcourt
Louiseville, Qc. J5V 2Z7

1-866-446-6667

Web: www.groleauinc.com

E-mail: contact@groleauinc.com

Directions for use Groleau PRO-766 glue

**Use these directions conjointly with GROLEAU
Prefinished 12" x 12" installation instructions.**

KEEP THE PRODUCT OUT OF REACH OF CHILDREN

IDENTIFICATION:

The **Groleau PRO-766** glue has been specially conceived to install **GROLEAU** prefinished parquet 12" x 12". The parquet may be quickly set in place with this high solid adhesive. It has excellent spread ability, adequate open time, high impact resistance and dimensional stability. This product is ready for use and non-flammable (Do not mix with any other material, solvent or liquid).

GENERALITY:

IMPORTANT: Keep glue from freezing

3.78 litres (1 gallon) of glue covers approximately 7 square meters (75 square feet).

Only use recommended glue when installing Groleau prefinished parquet 12" x 12", the use of any other kind of adhesive will automatically void the warranty over these products.

RECOMMENDATIONS:

Read carefully **Groleau** prefinished parquet 12" X 12" installation instructions before beginning applying glue to your floor.

For indoor and above ground level use only. This product is not recommended for kitchens, bathrooms or laundry rooms, or other damp areas. Sub floor humidity level should be under 11%. The sub floor should be made of dry plywood or dry concrete at their natural state. Do not paint, wax or seal your sub floor. Sub floor should be absolutely clean, level, smooth, well cured and completely dry.

Do not install parquet flooring directly over cork or any other insulating or soundproofing product. Do not install parquet flooring over radiant heated floor.

Room and material temperature should always be kept over 18°C (65°F).

Leave a minimum expansion space of 1.27cm (1/2") wide next to all walls and around fixed objects.

DIRECTIONS FOR USE:

Use a V notched trowel 1/8" X 1/8" X 1/8" to spread the adhesive on a limited area of 0.5 meter X 1 meter (1 1/2 ft X 3 ft). Press firmly on the trowel while applying the adhesive, there should be empty lines between each rank of glue. When you have finished spreading on the limited area, parquet sheets are immediately pressed firmly into place to cover the area.

Do not spread the glue on a too large area since the adhesive dries very fast and you will have trouble installing your sheets. The adhesive must be gummy when you apply your parquet over it. If you install your parquet on glue that has already begun to dry, the stability of your floor could be compromised.

When you spread the adhesive, you must make sure that there will be enough glue to attach each slate of the tile. Quantity left by the trowel is enough; do not put too much glue.

Use a humid cloth to clean your tiles.

Allow 24 hours-drying period before walking on your floor or before proceeding with other work on the covered area.



Groleau Flooring inc.
541, Dalcourt
Louiseville, Qc. J5V 2Z7

1-866-446-6667

Web: www.groleauinc.com

E-mail: contact@groleauinc.com